

AT AMKING TECHNOLOGIES WE PROVIDE TOMORROW'S CLEANING SOLUTIONS TODAY

TOLL FREE: 1-877-4-AMKING OR AT WWW.AM-KING.COM

Thank You for Purchasing the Environmentally Friendly MopKing Junior

Junior Operating Instructions:

IMPORTANT Before You Begin:

- Wash all Micro-Fiber or Rayon Blend mops in warm water before first use. Do not mix the mop types in wash. Follow the washing instructions on the mop label.
- Attach the folding mop frame to the handle by aligning the handle with the hole on the folding frame and insert "E" clip, then tighten the pressure fitting.

Daily Junior Operation:

- 1. **Remove** and **Charge** your Junior Battery **Daily** Failure to follow these instructions may result in equipment failure (Model # UB1270 12v 7Ah)
- 2. Fill solution tank (approximately 2 gallons) following chemical manufacturer's recommendation for proper chemical dilution. Replace tank, Align the supply hose inside between the tank and the bracket.
- 3. Load up to 15 flat mops into the mop magazine with the mop pockets facing up.
- 4. Collapse mop frame by stepping on the release button. Insert mop frame into mop magazine while aligning the mop frame with the flat mop pockets and push down to lock frame into flat mop.
- 5. Slowly lift the mop and guide the flat mop along the rail into wetting tray. The pump will automatically be activated and dispense the proper amount cleaning solution onto the mop head. Hold mop in wetting tray for approximately 2 seconds to absorb all of the solution.
- 6. Start mopping, working along the wall and in a "S" or "figure 8" pattern (See Figure #1 below) always the same leading edge of the flat mop. Change mop after 150-200 square feet or when the flat mop becomes dry.
- 7. Release dirty mop from the frame for laundering and repeat as necessary.

Use your Junior for Wet or Dry Mopping Floors, Walls, Baseboards, High Dusting and much more.

Junior Maintenance Tips:

- Clean wetting tray and mop magazine before reloading clean flat mops and fill solution tank.
- Remove battery when not in use, recharge battery as necessary on a daily basis.
- Junior Stainless maintenance, use a mild detergent and or stainless steel cleaner on the
 exterior of your Junior. The wetting tray and mop magazine can easily be removed
 and autoclaved.

Junior Limited Warranty:

The MopKing Junior has a 10 year warranty on the Stainless Steel, 2 years on the pump, and 1 year warranty on the battery and electronic components.




Figure #1